



# SWING & TWIST FILTRATION SYSTEMS

- Ideal for Water dispensers
- Refrigerators
- Dishwashers
- Coffee makers
- Ice makers
- Under-sink filtration.

Advanced, innovative, and oh so simple!

### Features:

- Automatic shut off filter head makes filter replacements safe and easy
- Compact design allows maximum use of space under sinks or behind water dispensers
- Cost saving Reduces servicing costs by saving time on filter changes
- Easy cartridge replacement -No housing spanners or tools required
- O'ring is on the filter New O'rings with every filter change
- Single, twin or triple filtration systems available.



8/5 McCourt Road, Yarrawonga NT 0832 1300 CANN NT (2266 68)

www.cannindustries.com

## SWING & TWIST FILTRATION SYSTEMS

#### **FILTER CARTRIDGE OPTIONS**

SEDIMENT CARTRIDGE	HOLLOW-FIBER
Polypropylene pre filter for the removal of dirt sediment, rust and particles.	Superior micro-fine membrane for the removal of bacteria.
Flow rate 2L per minute	Flow rate 2L per minute
Filter replacement – 3650L or 6 months. Which ever occurs first.	Filter replacement – 3000L or 6 months. Which ever occurs first.
5 micron	0.3
Minimum operating temp: 4-40C	Minimum operating temp: 4-40C

CARBON BLOCK	ULTRA CARBON BLOCK
Silver impregnated carbon block for chemical, taste and odour removal.	Silver impregnated carbon block for chemical, taste and odour removal.
Flow rate 2L per minute	Flow rate 2L per minute
Filter replacement – 3650L or 6 months. Which ever occurs first.	Filter replacement – 3000L or 6 months. Which ever occurs first.
5 micron	1 Micron
Minimum operating temp: 4-40C	Minimum operating temp: 4-40C

#### **DIMENSIONS CENTIMETRES**

	HEIGHT	WIDTH	DEPTH
Single	31	8	9
Twin	31	15.5	9
Triple	31	24	9



#### **Notes:**

- Filter should be pre flushed prior to attaching to equipment or after long periods of inactivity.
- Do not use with water that is microbiologically unsafe or of unknown quality.
- Turn water off to filter system if not in use for extended periods.
- Automatic shut off valve automatically shuts off water supply to the system when filter is removed.
- Filter life can vary depending on water quality and demand.
- A 350Kpa pressure limiting valve MUST be installed.
- Installation of your water filter system must only be carried out by a licensed technician and all aspects of the installation must comply with current local authority standards and regulations.
- Filter Head Systems come with 1/4" John Guest fittings as standard.

